



Uninstall Instructions

1. Go to Windows Control Panel
2. Go to "Program and Features" or "Add/Remove Programs"
3. Remove Diamond System Builder
4. Delete "ME" directory on C: drive.



5. Go to Roaming folder under your user name and delete "Mitsubishi"



6. Install Latest Version
7. Launch Diamond Builder
8. Run Check for Updates

